

Fryers:

**FD 80 D**

Spare parts

Since February 2010

Code	Qty	Spare part	Price
A14078	2	Knob	£5.79
A08009	2	Green pilot light	£11.45
A08003	2	Orange pilot light	£11.45
A06001	2	Safety thermostat	£24.48
H04082	4	Plastic control box side	£6.26
O7107	2	Lid	£25.66
A15015	2	Lid handle	£2.50
A06009	2	Thermostat	£46.12
C03011	2	Cord with plug	£21.64
F05003	2	Container	£116.32
D02023	2	Heating element	£82.25
F04006	2	Basket	£65.81
07110SE	1	Casing	£68.07
A13010	4	Foot	£0.42
A15016	2	Handle	£5.25
A07018	2	Microswitch	£9.00

Carriage and Packing charge : £10 per order  
Spare parts are non-returnable

