


Fryers:

FD 80 DR

Spare parts

Since February 2010

Ref	Code	Qty	Spare part	Price
1	A14078	2	Knob	£5.79
2	A08009	2	Green pilot light	£11.45
3	A08003	2	Orange pilot light	£11.45
4	A06001	2	Safety thermostat	£24.48
5	H04082	4	Plastic control box side	£6.26
6	O7107	2	Lid	£26.71
7	A15015	2	Lid handle	£2.50
8	A06009	2	Thermostat	£46.12
9	C03011	2	Cord with plug	£21.64
10	F05068	2	Container with waste outlet	£155.86
11	D02023	2	Heating element	£82.25
12	F04006	2	Basket	£65.81
13	07122SE	1	Casing	£77.73
14	B10014	2	Tap	£77.10
15	A10001	2	Cord closer	£2.35
16	A13010	4	Foot	£0.42
17	A15016	2	Handle	£5.25
18	A07018	2	Microswitch	£9.00



Carriage and Packing Charge : £10 per order
Spare parts are non-returnable