

Convection Oven - **FC340CN**

Spare Parts

Since April 2009

Ref	Code	Qty	Spare part	Price
1	H04093NO	1	Top casing	£42.51
2	H04157	2	Top/Bottom inside casing	£51.28
3	H03010	1	Seal	£9.12
4	15002GSE	1	Left side	£33.55
5	H04071NO	1	Left panel	£22.27
6	15007	1	Baking Tray	£28.78
7	F01031	3	Shelf / Grid	£22.62
8	B07002	2	Door Spring	£3.21
9	H04077NOSER	1	Door Frame	£76.77
10	15022	1	Holder glass	£6.64
11	A15047	1	Handle	£59.33
12	H01049	1	Glass	£20.19
13	H04068NO	1	Bottom casing	£65.95
14	A08009	1	Green pilot light	£11.45
15	A14090	2	Knob	£3.90
16	A13015	2	Foot	£9.62
17	H04094	1	Right panel	£34.74
18	A02019	1	Timer	£25.17
19	A13003	2	Rubber foot	£1.30
20	A08003	1	Orange pilot light	£11.45
21	A06042	1	Thermostat	£39.10
22	15002DSE	1	Right side	£33.55
23	A06035	1	Safety thermostat	£13.35
24	15230	1	Fan protection	£19.12
25	D02158	1	Heating element	£50.46
26	H04146	1	Back inside casing	£37.85
27	15231	1	Motor protecting	£10.68
28	A03044	1	Fan motor	£58.22
29	15229	1	Back rear	£23.75
30	A10002	1	Cord closer	£5.74
31	C03011	1	Cord with plug	£21.64

Carriage and Packing Charge : £10 per order
Spare parts are non-returnable

